



SPORTS—CLASSIC FOOTBALL—EASY ASSEMBLY INSTRUCTIONS

Assemble Each Part by the Numbers—Starting with Number One




TO REMOVE PARTS

From Sprue, Twist Part in Same Direction Several Times While Pulling Away from Sprue—or Cut with Scissors



6 10 YARD MARKER
Cut Marker Slide From 10 Yd. Marker & Snap Down onto "Chain"




PUSH MAGNET INTO PLACE

5 BALL MARKER
Remove 1, 2, 3 & 4 From Player Number Decal Sheet and Stick One Number on Each Side of "Box" To Use as Realistic Down Marker

4 GOALPOST
Place in Holes on Goalline for Pro—or at End of End Zone for College


3 SPEED CONTROL KNOB—Push Down onto Bolt

2 "MINUTE" WHEEL
Place Felt Washer on Shaft as Shown—Drop Shaft into Hole Provided in Gameboard



7 GOALLINE FLAG
Place in Holes Provided


1 "SECOND" WHEEL
Drop Shaft into Hole Provided in Gameboard



FELT FOOTBALLS


FELT WASHER

SHAFT



8 QUARTERBACK



- A. Hold leg at right angle to body.
 (1) Insert peg into hole in kicker body. While pressing leg firmly to kicker body,
 (2) rotate leg downward until foot touches base.



- B. Remove Players and Quarterback Running Bases from Their Sprues & Snap Quarterbacks onto Running Bases as Shown Above


9 SCORING KNOBS

- A. Punch Out all Cut-outs in Grandstand
- B. Assemble Each Knob and Scoring Disk by Pushing Knob Through Slot in Back of Disk—then Pushing Knob Through Round Hole in Back of Grandstand



10 ASSEMBLY OF GRANDSTAND:

- A. Fold both ends of grandstand back at scored line (a). (1) Fold slotted tab in and up. (2) Lock slotted tab into slot on bottom edge of grandstand.



- B. Bottom edge of gameboard rail fits onto protruding slotted supports at both ends of grandstand.

11

- ACCESSORY BAG** — Store Your Players and Other Small Parts in Your Accessory Bag. Use the "Kwik Lok" Fastener to Close the Bag.